Heating, Ventilation and Air Conditioning

In case of using the Split Unit both for heating and cooling. How to switch between both modes when using the split unit gateway SUG/U 1.1?

It is possible to use automatic mode or to switch via 1 bit group object ‘Simplified Mode’ to change over from heating to cooling and vice versa. The Split Unit Gateway also supports the standard KNX DPT 20.105 (HVAC control mode, 1 byte group object called Operating Mode).

Unique solution ID: #1496
Author: Carolina Bachenheimer-Schaefer
Last update: 2017-09-20 10:39

(c) 2024 ABB AG <knx.helpline@de.abb.com> | 19.03.2024 03:32
URL: https://faq.abb-buildingautomation.com/index.php?action=artikel&cat=44&id=496&artlang=en