

## Outputs

### **Is it possible to set a defined voltage at the outputs of the Analog Actuators in case of bus voltage failure?**

The AA/S is additionally supplied with an auxiliary voltage of 230 V.

Thus, in case the KNX voltage fails, a previously defined value can be approached at the output.

The AA/A powers itself using the bus voltage. Therefore, only the value after bus voltage recovery can be defined here.

Unique solution ID: #1237

Author: Carolina Bachenheimer-Schaefer

Last update: 2017-02-09 13:36