

# Outdoor Stations

## How to unlock default lock and 2nd lock by input password in Welcome M?

Default lock: #password#

2nd lock: #2#password#

Unique solution ID: #1103

Author: Leo-Yangeng.Li

Last update: 2017-03-09 08:30