Outdoor Stations

# How to open 2nd lock by swiping card in Welcome M?

You need to enter the OS setting, then set "Door Select" = 2nd-Lock.

modular design outdoor station:

Set the related door lock when swiping the card
#* system password # =>
Settings # =>Choose Door #

Choose Door
1st-Lock   ∧
2nd-Lock
                  ∨

Setting the lock that will be released when swiping the registered card:

Unique solution ID: #1104
Author: Leo-Yangeng.Li
Last update: 2017-03-09 08:37