

# Outdoor Stations

## **When there is a trigger of the binary input for magnetic door contact in Welcome outdoor Station (door status check), where will the alarm be display?**

The alarm signal will be send to indoor station and guard units, the LED status of the door unlock button will flash.

For more information please check our System Manual:

[https://library.e.abb.com/public/298d6c313822445584beea5e6fbcdd1/2TMC107015M0201\\_WelcomeSystemManual.pdf](https://library.e.abb.com/public/298d6c313822445584beea5e6fbcdd1/2TMC107015M0201_WelcomeSystemManual.pdf)

Unique solution ID: #1287

Author: Carolina Bachenheimer-Schaefer

Last update: 2016-12-07 12:17