

Outdoor Stations

What happens if you enter the wrong password into the ABB-Welcome (M) outdoor station?

After three (3) failed attempts to enter your password the device will be blocked for 15 seconds.

Unique solution ID: #1430

Author: Carolina Bachenheimer-Schaefer

Last update: 2017-08-17 12:07