

# DALI

## Can you operate a DALI Light Controller without connected DALI devices?

A simulation of the assigned DALI devices takes place in the DALI Light Controllers. When control is switched on or activated, feedback from the assigned DALI devices is expected on the DALI side. In order to bypass this, the dimming times for switching and brightness must be set to "Jump to" for all affected groups in the DLR/S.

Unique solution ID: #1225

Author: BA Engineering Team

Last update: 2024-10-29 08:41