

# DALI

## **At the DALI gateways DG/S 1.1, DG/S 1.16.1 and DG/S x.64.1.1 the yellow DALI LED flashes permanently. What is the reason for this?**

As long as the yellow DALI LED flashes the gateway is in the initialization phase. This usually lasts 60-90 seconds.

If the gateway remains permanently in this state the cause may be that more than 64 participants are connected.

All other LED states can be found in the product manuals.

Unique solution ID: #1614  
Author: BA Engineering Team  
Last update: 2024-10-29 08:43