

DALI

DG/S x.64.5.1: Can I set “standby switch-off” individually for single ballasts or groups?

No, this is not possible. Standby switch-off always applies to all devices of a channel. Therefore, the “only” distinction that can be made with a 2-channel device is between channel A and channel B.

Unique solution ID: #1722

Author: BA Engineering Team

Last update: 2020-04-08 14:31