

# Commissioning and Configuration

## How to update the free@home firmware?

Login with a computer or table while in configuration mode and go to preferences at the right bottom of the screen. There you will find the "update" option.

For a more detailed explanation please check our video tutorial:

Link to this  
video:

<https://www.youtube.com/embed/qFRVFpRmPOE?feature=youtu.be&html5=1&rel=0&wmode=transparent>

Unique solution ID: #1263

Author: Carolina Bachenheimer-Schaefer

Last update: 2017-02-10 12:26