

# Heating, Ventilation and Air Conditioning

## What must be considered when mounting the room temperature controller/CO2/humidity to avoid false relative humidity measurements?

To avoid false measurements of the relative humidity, the device must be mounted in a windproof flush-mounted box. Furthermore, installations with empty conduits help to prevent draughts.

Unique solution ID: #1381

Author: Carolina Bachenheimer-Schaefer

Last update: 2017-03-22 11:26