

Heating, Ventilation and Air Conditioning

SUG/U 1.1: Will the time from the function "On/Off delay" be added to the time from the window contact?

No. Only the timer from the window contact is executed.

Unique solution ID: #1438

Author: Kevin Klemm

Last update: 2017-09-04 08:25