

# Heating, Ventilation and Air Conditioning

## FCC/S 1.x.x.1: Why does the current setpoint changes to 7°C when an open window is detected?

This means that the function “building protection” is active. This protection function can be send via the device status byte and also via status operating mode of the controller.

Unique solution ID: #1573

Author: Marcel Feuerstein

Last update: 2018-07-09 14:14