

# Heating, Ventilation and Air Conditioning

## **FCC/S 1.x.x.1: Why does the fan directly switch into the speed level depending on the control value if the fan mode is set to “step”?**

This is implemented in the application of the fan coil controller and supports the technical requirements of the fan.

Unique solution ID: #1580

Author: Marcel Feuerstein

Last update: 2018-07-04 14:51