

Heating, Ventilation and Air Conditioning

Why does the HCC/S 2.x.x.1 in case of a pump error or an activated repair switch not switch off the relay for the pump?

The monitoring has to be set in the parameters of the ETS:

Monitoring and safety	Activate manual pump overdrive via group object	<input checked="" type="radio"/> No <input type="radio"/> Yes
Pump		
a: Supply flow temperature	Monitor pump status	<input checked="" type="radio"/> Deactivated <input type="radio"/> Via physical device input
b: Return flow temperature	Monitor pump error	Via group object
c: Binary input	Monitor pump repair switch	Via group object

Please check if the parameters for "pump error" and "pump repair switch" are activated.

Unique solution ID: #1638
Author: BA Engineering Team
Last update: 2019-02-14 10:41