

# Heating, Ventilation and Air Conditioning

## **HCC/S 2.x.x.1: Which state has got the controller without a valid supply flow temperature?**

If the controller does not receive a valid supply flow temperature after a download, bus voltage recovery or reset, it is in an undefined state. The requirements for switching between heating and cooling and also for control On/Off getting lost.

This condition will be maintained until a valid supply flow temperature is received.

Unique solution ID: #1643

Author: Marcel Feuerstein

Last update: 2019-02-12 15:57