Heating, Ventilation and Air Conditioning

AC/S 1.x.1: What needs to be considered if "Room involvement" is activated during comissioning?

In the default parameter, the calculation of the control value starts with a delay of 45 minutes. For commissioning, it is advisable to choose the delay much less.

Room involvement	The control value of all valves of this heating distribution circuit must be connected to the ASM input socket!
Increase supply temperature	10 ♦ K
Decrease supply temperature	-10 ♦ K
Optimum room control value	70 🗘 %
Controller proportional factor Xp	30 ❖ %
Room involvement calculation delay	00:45:00 💠

Unique solution ID: #1672 Author: BA Engineering Team Last update: 2019-04-02 15:09