


# Heating, Ventilation and Air Conditioning

## AC/S 1.x.1: Where can I see which color is assigned to which data point type?

With the "mouse-over-function" on the corresponding socket in the linking view, the data point type is displayed.



Unique solution ID: #1675  
Author: BA Engineering Team  
Last update: 2019-04-03 13:31