

# Heating, Ventilation and Air Conditioning

## AC/S 1.x.1: How are the rights of the different user profiles defined?

Each user has its own rights. You can find the definition in the product manual (chapter 7.2.2.4).

[AC/S product manual](#)

User profile	Rights
admin	"Administrator" This user has all rights <ul style="list-style-type: none"><li>• Change everything in the ASM detailed view on the web user interface</li><li>• Change web user interface settings</li><li>• Undertake firmware updates</li><li>• Delete messages</li></ul>
expert	"Expert" This user has the following rights: <ul style="list-style-type: none"><li>• Change everything in the ASM detailed view on the web user interface</li></ul>
user	"User" This user has the following rights: <ul style="list-style-type: none"><li>• Change the normal settings in the ASM detailed view on the web user interface. Expert settings are read-only.</li></ul>
viewer	"Viewer" This user has the following rights: <ul style="list-style-type: none"><li>• Can read all settings in the ASM detailed view on the web user interface, but not change them.</li></ul>
without login	"Without login" This user profile can be used to make ASMs visible even without logging into the web user interface. In this situation, the following rights are possible: <ul style="list-style-type: none"><li>• Can read all settings in the ASM detailed view on the web user interface, but not change them.</li></ul>

Unique solution ID: #1682

Author: BA Engineering Team

Last update: 2019-04-04 15:11