

Outputs

SAH/S x.x.7.x: Why are all channels configured as shutter actuator in the factory state?

This is a safety measure, because the relays are **not** mechanically interlocked. It prevents both phases (for moving up and down) of a connected shutter/blind drive from being energized simultaneously. This is why the channels are predefined as Shutter actuators.

Unique solution ID: #1713

Author: BA Engineering Team

Last update: 2020-03-20 08:31