Outdoor Stations

When does the alarm signal of door status check alarm signal of outdoor station send in Welcome M?

When the door is opened for more than 120s, the alarm signal will be sent to every Indoor station and Guard unit related to this Outdoor station.

The "unlock' key of Indoor station will flash.

Unique solution ID: #1101
Author: Leo-Yangeng.Li
Last update: 2017-03-09 04:57

(c) 2024 ABB AG <knx.helpline@de.abb.com> | 19.03.2024 11:09
URL: https://faq.abb-buildingautomation.com/index.php?action=artikel&cat=114&id=102&artlang=en