Heating, Ventilation and Air Conditioning

AC/S 1.x.1: How are the rights of the different user profiles defined?

Each user has it´s own rights. You can find the definition in the product manual (chapter 7.2.2.4).

AC/S product manual

User profile	Rights
admin	"Administrator" This user has all rights • Change everything in the ASM detailed view on the web user interface • Change web user interface settings • Undertake firmware updates • Delete messages
expert	"Expert" This user has the following rights: • Change everything in the ASM detailed view on the web user interface
user	"User" This user has the following rights: • Change the normal settings in the ASM detailed view on the web user interface. Expert settings are read-only.
viewer	"Viewer" This user has the following rights: • Can read all settings in the ASM detailed view on the web user interface, but not change them.
without login	"Without login" This user profile can be used to make ASMs visible even without logging into the web user interface. In this situation, the following rights are possible: • Can read all settings in the ASM detailed view on the web user interface, but not change them.

Unique solution ID: #1682
Author: BA Engineering Team
Last update: 2019-04-04 15:11

(c) 2024 ABB AG <knx.helpline@de.abb.com> | 28.03.2024 15:42
URL: https://faq.abb-buildingautomation.com/index.php?action=artikel&cat=44&id=681&artlang=en